


## Four Terminal Coin Cell Holder



---

Lifting the coaxial pin When detaching the coin battery with tweezers,

The coin battery can be moved horizontally, and it can be detached easily.